

M22B and M50B

G-45-15

3-point 24Vac or 230 Vac Valve actuator for size DN125 – DN150

2 April 2004

M22B and M50B are electromechanical actuators for motorizing 2-way and 3-way valves large sizes DN125 and DN150 type V222, V292 and V321

M22B and M50B actuators are powered by 24 Vac or 230 Vac and controlled by 3-point action (inc./dec.)

The actuators have optional end switches

M22B and M50B can be ordered mounted in factory on the valve. See data sheet F-10-6



TECHNICAL SPECIFIC	CATION		
Part numbers see the table below		Material:	
		Housing	CoPA - Grivory GV-4H
Running time:		Cover	PC - Polycarbonat
3-point 0 -50 mm (0 - 2 in	.) 13	2 s Color	black/blow
	60Hz 1 ²	2 s Weight	
Thrust	M22B . 2200 N (495	lbf)	M50B6,0 kg (13,2 lb.)
	M50B 5000 N (1120	lbf) Dimensions (mm))
Duty cycle	max. 80%/60 minu	tes	

Optional travel switch S2:

Ambient temperature:

Operation —20 – +70 °C (-4°F - 158°F)

Storage —20 – +70 °C (-4°F - 158°F)

Ambient humidity <95 %RH


Enclosure rating IP 65

Standards:

Emission —EN 50081-1: 03.1993

Immunity —EN 50082-1: 11.1997

EN 50082-2: 02.1996



Part number	Description		Power consumption	
		Power supply	50 Hz	60Hz
890-0106-000	M22B-24V	24 Vac+10%/ -15%	12 VA	15 VA
890-0108-000	M22B-24V-S2V	24 Vac+10%/ -15%	12 VA	15 VA
890-0110-000	M22B-230V	230 V AC +10% / -15%	11 VA	14 VA
890-0112-000	M22B-230V-S2V	230 V AC +10% / -15%	11 VA	14 VA
890-0206-000	M50B-24V	24 Vac+10%/ -15%	19 VA	29 VA
890-0208-000	M50B-24V-S2	24 Vac+10%/ -15%	19 VA	29 VA
890-0210-000	M50B-24V	230 V AC +10% / -15%	28 VA	35 VA
890-0212-000	M50B-24V-S2	230 V AC +10% / -15%	28 VA	35 VA

FUNCTION

The actuator

M22A and M50A consists of a reversible motor and a gear train in a CoPA housing.

All bearings of motor and gear train are of permanent lubrication type.

The reversible motor cuts out in both end positions on activating limit switches

Additional swiches

The actuators can be optional equipped with an additional stroke-switch board containing two travel switches (double-throw contacts (S4 and S5). These switches can be adjusted to switch anywhere within the working range.

Manual operation

The actuator can be manually operated by means of a hand wheel. Since the hand wheel always follows during motor-driven operation (running indication), never operate by hand while the actuator is running – potential injury hazards


Note: Switch of the electrical source and secure against turning on again.

The position of the actuator is indicated with a pointer between the actuator and the valve.

WIRING

M22B and M50B

M22B-S2 and M50B-S2



INSTALLATION

The installation of the M22B and M50B is carried out according to instruction, shipped together with the actuator, if the actuator is mounted on the valve from factory.

How to mount and adjust a M22B and M50B actuator to a valve is described in the handbook for M22 and M50.

The actuator may be mounted beside or above the valve. Mounting below the valve should be avoided

2(2) 0-003-2798-0 (EN)